

# Dispenser Instruction

## 1. Dispenser Features

**Auto Dispense:** Auto Dispense by Sensor, touch free to avoid cross infection.

**Power Supply:** Dispenser power supplied by LCD screen.

**Dispensing Life:** The life of our dispenser is more than 650000 times.

## 2. Dispenser Operation

1. Use Key to open front housing.
2. Take out white refilling bottle.
3. Unscrew nozzle by hand.
4. Filling the bottle.
5. Fitting bottle.
6. Close the housing.
7. The longest induction distance between hand and dispenser jet nozzle is within 7cm.

